

## **Instructions for Receiving Adventist Channels on New Satellite**

### **MANHATTAN DSR 1500**

1. Using your Manhattan remote control press "SETUP" button (located above the #3 button)
2. Press \*down arrow and highlight "SYSTEM SETTING"
3. Press OK button
4. Press \*down arrow and highlight "DEFAULT SETTING"
5. Press OK button and the screen will display "WARNING: THIS WILL RESET ALL SETTINGS TO DEFAULT VALUES" (If you see "OK" on screen go to step 6; if you DO NOT see "OK" on screen, press "OK" on remote control, then go to step 10)
6. Press \*right arrow to select "OK"
7. Press OK button and the screen will display "WARNING: ARE YOU SURE YOU WANT TO CONTINUE"
8. Press \*right arrow to select "OK"
9. Press OK button
10. Screen will Display "PLEASE WAIT" then "STORED SETTINGS RESET TO DEFAULT", press OK button to restart the receiver.
11. Screen displays LANGUAGE SELECTION, press OK button.
12. Press \*down arrow to "TP FREQUENCY"
13. Using the number buttons on the remote control enter the numbers 11842
14. Press \*down arrow to select POLARIZATION should be "HOR"
15. Press \*down arrow to 'SYMBOL RATE'
16. Using the number buttons on the remote control enter the numbers 22000

### **SEE "INSTRUCTIONS FOR MOVING THE DISH"**

**IMPORTANT: DO NOT PROCEED TO NEXT STEP UNTIL READJUSTING THE DISH.**

17. When you have the maximum yellow/green bar on "Signal Strength", press \*down arrow to "Start Search" (there will be quotation marks "" on either end of Start Search when it is selected)
18. Press the OK button
19. A box will pop up to the right. When you see the word "Store" at the bottom of that box press OK button
20. Screen will display "CHANNEL DATA IS BEING UPDATED" then return to a TV viewing screen.

\*DIRECTIONAL ARROWS ON THE REMOTE CONTROLS ARE THE "CHANNEL UP BUTTON (UP ARROW), CHANNEL DOWN BUTTON (DOWN ARROW), VOLUME UP BUTTON (RIGHT ARROW), VOLUME DOWN BUTTON (LEFT ARROW)

## **MANHATTAN SKYLINE 1000**

1. Using your Manhattan remote control press the “Menu” button
2. Press the \*down arrow to highlight “Master Reset”
3. Press the OK button two (2) times and the screen will display “Resetting - Please Wait”
4. Press ESC button to exit “OSD SETUP”
5. Press ESC button to exit “TV SETTINGS”
6. Press ESC button to exit “TIME SETTINGS” (or enter time settings and select STORE and press OK)
7. Press ESC button to exit “ANTENNA SETTINGS”
8. Press \*down arrow to highlight “Search Mode”
9. Press \*left arrow to select “Manual FTA”
10. Press the channel down button to highlight “TP DATA”
11. Press OK button
12. A box will pop up to the right. At the top of that box, in yellow, make sure it says “TP1:3ABN”, if not, push the \*left or right arrow to get to “TP1:3ABN”
13. Press \*down arrow to “FREQ” (frequency)
14. Using the number buttons on the remote control enter the numbers 11842
15. Press \*down arrow to “Polarity”
16. Should read “HORZ”, if not press \*left arrow to select “HORZ.”
17. Press \*down arrow to “S/R” (symbol rate)
18. Using the number buttons on the remote control enter the numbers 22000
19. Press \*down arrow to “FEC”
20. Should read  $\frac{3}{4}$ , if not press \*left arrow to select  $\frac{3}{4}$
21. Press \*down arrow to “STORE”
22. Press OK button and screen will display “Storing Data – Please Wait”

## **SEE “INSTRUCTIONS FOR MOVING THE DISH”**

**IMPORTANT: DO NOT PROCEED TO NEXT STEP UNTIL READJUSTING THE DISH.**

23. When you have the maximum strength on the two green bars (both Signal and Quality) press \*down arrow to “START”
24. Press OK button and upon channel scan completion the screen will display “Resetting – Please Wait”
25. Press OK button to continue

**\*DIRECTIONAL ARROWS ON THE REMOTE CONTROLS ARE THE “CHANNEL UP BUTTON (UP ARROW), CHANNEL DOWN BUTTON (DOWN ARROW), VOLUME UP BUTTON (RIGHT ARROW), VOLUME DOWN BUTTON (LEFT ARROW)**

**TO DETERMINE WHICH TOPFIELD RECEIVER YOU HAVE TURN THE RECEIVER BOX OVER AND LOOK AT THE BOTTOM. THERE IS A STICKER ON THE BOTTOM THAT WILL SAY TF3000Fi, TF4000Fi OR TF6200F**

### **TOPFIELD 3000**

1. Using your Topfield remote control push "Menu" button
2. Press \*down arrow to highlight "Installation"
3. Press OK button
4. Press \*down arrow to select "Factory Setting"
5. Press OK button to display "Reset All Data"
6. Press \*left arrow to select "Yes"
7. Press OK button to display "Position Data Delete"
8. Press \*left arrow to select "Yes" and then press "OK"
9. Press OK button to continue
10. Press \*up arrow to select "SAT/TP Edit"
11. Press OK button again on "Satellite Name" (A box with a list of satellite names will pop up on the right hand side)
12. Press \*down arrow to select "Telestar5(KU)" or "Intel\_Amc5(KU)" **NOTE: SOME OF THE MODEL 3000's DO NOT HAVE A LIST OF SATELLITE NAMES, IF THERE ARE NO OTHER NAMES, SELECT "OTHERS".**
13. Press OK button
14. Press \*down arrow to select "Add new TP"
15. Press OK button to display new window "Add New TP – "Frequency" will be highlighted in white.
16. Using the number buttons on the remote control enter the numbers 11842
17. Press \*down arrow to select "Symbol Rate"
18. With the number buttons on the remote control enter the numbers 22000
19. Press \*down arrow to select "Polarization" and push the \*right arrow one time and it should read "Horizontal"
20. Press \*down arrow to the word "OK" and press the OK button on the remote control.
21. Press \*down arrow to select "Channel Search" and press the OK button on the remote control.
22. In the lower right hand corner you will see two bars, one says "Level" and one says "Quality". You should have a green "Level" bar
23. Press \*down arrow to select "Search Mode" then press \*right arrow one time and it should read "Manual"

**SEE "INSTRUCTIONS FOR MOVING THE DISH"**

**IMPORTANT: DO NOT PROCEED TO NEXT STEP UNTIL READJUSTING THE DISH.**

24. Press \*down arrow to select "FTA/Scrambled" and press \*right arrow to read "FTA Only"
25. Make sure you have a yellow Quality bar then press \*down arrow to select "Start Search"
26. Press OK button and a "Searching" screen will appear.
27. When Channel Scan is completed press OK, the Channel Search Screen will appear.
28. Press EXIT button to exit and view programming.

**\*DIRECTIONAL ARROWS ON THE REMOTE CONTROLS ARE THE "CHANNEL UP BUTTON (UP ARROW), CHANNEL DOWN BUTTON (DOWN ARROW), VOLUME UP BUTTON (RIGHT ARROW), VOLUME DOWN BUTTON (LEFT ARROW)**

## **TOPFIELD 4000, 6200**

1. Using your Topfield remote control push “Menu” button
2. Press \*down arrow to highlight “Installation”
3. Press OK button
4. Press \*down arrow to select “Factory Setting”
5. Press OK button to display “Reset All Data”
6. Press \*left arrow to select “Yes”
7. Press OK button to display “Position Data Delete”
8. Press \*left arrow to select “Yes” and then press “OK”
9. Press OK button to continue
10. Press \*up arrow to select “SAT/TP Edit”
11. Press OK button again on “Satellite Name” (A box with a list of satellite names will pop up on the right hand side)
12. Press \*down arrow to select “Intel\_Amer5(KU)”
13. Press OK button
14. Press \*down arrow to select “Add new TP”
15. Press OK button to display new window “Add New TP – “Frequency” will be highlighted in white.
16. Using the number buttons on the remote control enter the numbers 11842
17. Press \*down arrow to select “Symbol Rate”
18. With the number buttons on the remote control enter the numbers 22000
19. Press \*down arrow to select “Polarization” and push the \*right arrow one time and it should read “Horizontal”
20. Press \*down arrow to the word “OK” and press the OK button on the remote control.
21. Press \*down arrow to select “Service Search” and press the OK button on the remote control.
22. In the lower right hand corner you will see two bars, one says “Level” and one says “Quality”. You should have a green “Level” bar
23. Press \*down arrow to select “Search Mode” then press \*right arrow one time and it should read “Manual”

### **SEE “INSTRUCTIONS FOR MOVING THE DISH”**


**IMPORTANT: DO NOT PROCEED TO NEXT STEP UNTIL READJUSTING THE DISH.**

24. Press \*down arrow to select “FTA/Scrambled” and press \*right arrow to read “FTA Only”
25. Press \*down arrow to select “Start Search”
26. Press OK button and a “Searching” screen will appear.
27. When Channel Scan is completed press OK, the Service Search Screen will appear.
28. Press EXIT button to exit and view programming.

**\*DIRECTIONAL ARROWS ON THE REMOTE CONTROLS ARE THE “CHANNEL UP BUTTON (UP ARROW), CHANNEL DOWN BUTTON (DOWN ARROW), VOLUME UP BUTTON (RIGHT ARROW), VOLUME DOWN BUTTON (LEFT ARROW)**

## INSTRUCTIONS FOR MOVING THE DISH


1. Go outside to the dish. Mark the current position of the dish on the mast pipe and the current elevation angle. Slightly loosen the bolts that secure the dish to the vertical mast pie, while standing behind the dish move the satellite dish lightly to the left (EAST). Have someone else inside looking at the TV screen. When you are on the G-19 satellite you will get two green bars, one on the signal and one on the “Quality” (on the Manhattan Skyline 1000), a yellow/green bar on the “Signal Strength” on the (Manhattan DSR 1500), on the Topfield receivers you will get a yellow bar on the “Quality” bar.



2. You may have to adjust the elevation to receive the new satellite. If you are in the central US or Canada, minimal or no elevation change will be necessary. If you are in the eastern part of the US or Canada, slightly raise the dish approximately 2 degrees. If you are in the western part of the US or Canada slightly lower the dish approximately 2 degrees. Slightly loosen the bolts that lock the elevation angle. Once the Quality bar/Signal Strength bar is at the highest reading, tighten the dish mounting and elevation.



3. Slightly loosen the screws of the clamp that holds the LNBF. Slowly rotate the LNBF clockwise or counter clockwise to peak the Quality/Signal Strength bar. If you or an installer need the exact aiming coordinates for the satellite, please visit the website [www.GeoSatFinder.com](http://www.GeoSatFinder.com) then enter your ZIP code and select your city



**Programming Scientific Atlanta  
PowerVu Model D9850**

**3ABN Galaxy 19 Ku Band**

1. Step by step programming Instruction.
  - a. Press **"MENU"** and using the "arrows to highlight **"Preset"** and press **"Select"** Button.
  - b. Using the arrow **"down"** button to highlight **"Frequency"** and press **"Select"**, and using arrow **"right"** button to highlight continue and press **"Select"**, and using the numeric key pad enter the frequency **"11842000"** and press **"Select"**.
  - c. Using the **"right"** or **"left"** arrow highlight **"\* Symbol Rate"** and press **"Select"** then enter the Symbol Rate number by using key pad **"22000"** and press **"Select"**
  - d. Highlight **"FEC"** and press **"Select"**, then using **"Up"** or **"Down"** arrow, choose **"3/4"** and press **"Select"**.
  - e. Using the **"Down"** arrow highlight **"Input"** and press **"Select"** and making sure the input cable from the LNB is connected to input **No. 1**, choose **"RF 1"** then press **"Select"**.
  - f. Using the **"Down"** arrow choose **"L01"** and press **"Select"** then using the key pad enter **"10750000"** and press select.
  - g. Using the **"Down"** arrow choose **"Satellite"** and press **"Select"** then, using the **"Up"** or **"Down"** arrow, choose **"AMC 5"** satellite and press **"Select"**. and using the **"Right"** arrows choose **"Polar"** and press **"Select"**, then, using the **"Up"** or **"Down"** arrows choose **"H"** and press **"Select"**.
  - h. Using the **"Down"** arrow choose **"Power"** and press **"Select"** then using the **"Up"** or **"Down"** arrow choose **"18"** and press **"Select"**
  - i. Press **"MENU"** and choose **"Continue"** and press **"Select"** and press **"MENU"** again to see if the desired signal is coming in. **CH 1 is TV English, CH 2 is TV Latino, 3ABN Radio and Radio 74.**

1. Press Menu button on Pansat remote control.
2. Press CH. down button to “Installation”
3. Press **enter button (button in the center of the CH. and VOL. buttons)**
4. Will ask for password, press numbers 0000 (or if you have chosen a different password, put that in)
5. Press CH. down to “Factory Set”
6. Press enter button
7. Press enter button again
8. Press CH. up to “TP Edit/Scan”
9. Press enter button
10. Press CH. down to “TP Frequency”
11. Press the number buttons 11842
12. Press CH. down make sure it says “Horizontal”
13. Press CH. down to “Symbol Rate”
14. Press the number buttons 22000
15. Press CH. down to “Scan”
16. Press VOL. up (arrow pointing to right) to choose “Free Only”
17. Press enter button. When scanning is complete, press “Exit” button **3 times** to view programming.